






IX (世界測地系) 埼玉県川口市境界確定図

-9・450

-22・375



A 本町一丁目



元郷一丁目

- ▽ 2級基準点
- ⊙ 3級基準点
- ⊕ 細部図根点
- ⊗ 市石杭
- ◇ 市プレート
- ⊕ 市板
- ⊕ 国調プレート
- ⊕ 民石杭
- ⊕ 民プレート
- ⊗ 民板
- ⊗ 国石杭
- ⊕ 国プレート
- ⊕ 県石杭
- ⊕ 県プレート
- J R石杭等
- J Rプレート等
- 計算点

-22・500

-9・625

座標一覧表


点名	X座標	Y座標
0012100		
0012100-10	-22377.157	-9612.091
0012100-11	-22384.383	-9613.905
0012100-12	-22389.765	-9618.992
0012100-13	-22392.616	-9621.640
0012100-14	-22394.621	-9619.506
0012100-15	-22396.612	-9621.573
0012100-16	-22394.869	-9623.730
0012100-17	-22397.743	-9626.398
0012100-42	-22386.371	-9615.784
0012100-43	-22390.444	-9619.623
0012100-44	-22391.767	-9620.852
0012100-45	-22396.223	-9624.987
0012100-46	-22396.691	-9625.421
0012100-47	-22397.811	-9626.439
0012111		
0012111-25	-22377.312	-9507.419
0012111-26	-22381.598	-9510.367
0012111-27	-22384.021	-9511.916
0012111-28	-22384.098	-9511.964
0012111-29	-22387.075	-9513.755
0012111-30	-22389.266	-9515.000
0012111-31	-22390.945	-9515.912
0012111-32	-22394.581	-9517.774
0012111-33	-22400.028	-9520.280
0012111-34	-22405.592	-9522.510
0012111-35	-22407.598	-9523.256
0012111-36	-22403.902	-9533.028
0012111-37	-22413.628	-9538.900
0012111-38	-22416.241	-9540.550
0012111-39	-22417.702	-9547.603
0012111-40	-22414.923	-9557.409
0012111-41	-22413.747	-9579.330
0012111-42	-22405.771	-9596.115
0012111-43	-22392.954	-9585.272
0012111-44	-22378.813	-9571.822

座標一覧表

点名	X座標	Y座標
0012112		
0012112-01	-22410.915	-9600.217
0012112-02	-22414.019	-9593.659
0012112-03	-22420.050	-9580.911
0012112-04	-22421.242	-9558.491
0012112-05	-22424.285	-9547.856
0012112-06	-22420.720	-9530.965
0012112-07	-22424.511	-9529.537
0012112-08	-22448.276	-9538.392
0012112-09	-22450.810	-9539.335
0012112-10	-22452.026	-9539.787
0012112-11	-22453.578	-9540.485
0012112-12	-22456.045	-9542.181
0012112-13	-22457.500	-9543.674
0012112-14	-22458.101	-9544.361
0012112-15	-22460.321	-9546.373
0012112-16	-22462.858	-9547.965
0012112-17	-22464.657	-9548.755
0012112-18	-22488.304	-9557.553
0012112-19	-22490.557	-9558.392
0012112-20	-22466.803	-9620.399
0012112-21	-22457.115	-9625.089
0012112-22	-22455.173	-9624.525
0012112-23	-22438.294	-9617.386
0012112-24	-22422.367	-9608.314
0012112-25	-22420.477	-9572.893
0012112-26	-22420.650	-9569.631
0012112-27	-22485.935	-9570.458
0012112-28	-22458.040	-9624.642
0012112-29	-22438.204	-9617.335
0012112-30	-22414.885	-9603.132

座標一覧表

点名	X座標	Y座標
基準点座標		
T1T1-TF182-3A	-22400.727	-9602.012
T1T1-TF186-1	-22399.844	-9624.350
T1T1-TF190-1	-22425.276	-9626.140
T1T1-TF191-1	-22416.004	-9571.494
T1Z1-TF11-1	-22460.211	-9543.100
T1Z1-TF12-1	-22489.045	-9623.728
T1交46	-22406.412	-9606.946
T1交47	-22419.440	-9524.912



T'53-1	T'53-2	
T'53-3		