


座 標 一 覧 表

点 名	X座標	Y座標
基準点座標		
20D73	-21711.472	-9734.219
R21K04	-21701.914	-9786.851
R2105-1	-21715.396	-9762.573
R2109-1	-21734.825	-9798.698
0022100		
0022100-03	-21711.661	-9794.460
0022100-04	-21723.564	-9796.917
0022110		
0022110-01	-21712.751	-9789.119
0022110-02	-21722.882	-9739.237
0022110-03	-21726.662	-9736.477
0022110-08	-21725.033	-9791.603



A 栄町二丁目
B 幸町一丁目



T'22-4		
T'32-2	T'33-1	