



座標一覧表

点名	X座標	Y座標
0012050		
0012050-01	-22033.292	-9789.424
0012050-02	-22030.110	-9784.937
0012050-03	-22044.607	-9713.465
0012050-04	-22050.111	-9686.239
0012050-05	-22054.653	-9664.299
0012050-06	-22059.906	-9638.050
0012050-11	-22126.243	-9704.324
0012050-12	-22122.884	-9741.109
0012050-13	-22122.605	-9744.547
0012050-14	-22123.779	-9750.473
0012050-19	-22111.728	-9799.748
0012050-20	-22096.507	-9797.834
0012050-21	-22084.301	-9796.291
0012050-22	-22069.157	-9794.299
0012050-23	-22060.016	-9793.043
0012050-24	-22052.885	-9792.063
0012050-25	-22035.422	-9758.747
0012050-26	-22037.545	-9748.281
0012050-27	-22040.740	-9732.529
0012050-28	-22042.612	-9723.302
0012050-29	-22056.843	-9653.355
0012050-30	-22069.357	-9640.193
0012050-31	-22078.146	-9642.186
0012050-32	-22086.125	-9643.996
0012050-33	-22091.574	-9645.231
0012050-34	-22099.727	-9647.080
0012050-35	-22110.406	-9649.502
0012050-36	-22117.463	-9651.102
0012050-37	-22123.263	-9652.417
0012050-38	-22124.269	-9652.645
0012050-42	-22122.922	-9740.691
0012050-43	-22122.990	-9746.489
0012050-45	-22106.989	-9799.152
0012050-46	-22094.075	-9797.527
0012050-47	-22081.028	-9795.861
0012050-48	-22067.353	-9794.051
0012050-49	-22053.056	-9792.087

座標一覧表

点名	X座標	Y座標
0012060		
0012060-18	-22052.811	-9636.441
0012060-19	-22047.526	-9662.849
0012060-20	-22043.038	-9684.530
0012060-21	-22039.433	-9702.360
0012060-22	-22022.694	-9784.899
0012060-23	-22017.893	-9785.955
0012060-43	-22028.855	-9631.011
0012060-44	-22040.229	-9633.589
0012060-45	-22050.905	-9645.963
0012060-46	-22045.294	-9673.631
0012060-47	-22029.835	-9749.689
0012060-48	-22027.662	-9760.402
0012060-49	-22026.693	-9765.182
0012060-50	-22006.095	-9783.583
0012060-51	-22005.702	-9783.504
0012070		
0012070-24	-22057.566	-9631.919
0012070-34	-22094.099	-9640.203
0012070-35	-22067.503	-9634.172
0012070-36	-22048.431	-9629.849
0012070-37	-22042.978	-9628.613
0012070-38	-22037.242	-9627.313
0012070-39	-22031.506	-9626.013

座標一覧表

点名	X座標	Y座標
基準点座標		
R21K09	-22019.740	-9799.669
T1T1-TF161-1	-22028.918	-9790.535
T1T1-TF161-2	-22039.229	-9737.081
T1T1-TF161-3	-22043.179	-9686.606
T1T1-TF162-1	-22020.469	-9628.607
T1T1-TF163-1	-22091.748	-9640.196
T1T1-TF167-3	-22124.474	-9728.058
T1交32	-22060.445	-9633.090
T1交32A	-22050.673	-9681.206



	T <sup>1</sup> 33-3	T <sup>1</sup> 33-4
T <sup>1</sup> 42-2		T <sup>1</sup> 43-2
T <sup>1</sup> 42-4	T <sup>1</sup> 43-3	T <sup>1</sup> 43-4

⊕	基準点
⊗	市石杭
◇	市プレート
⊕	市鋳
□	国調プレート
⊕	民石杭
⊕	民プレート
⊗	民鋳
⊗	国石杭
⊗	国プレート
⊗	県石杭
⊗	県プレート
○	JR石杭等
□	JRプレート等
●	計算点