

座標一覧表

点名	X座標	Y座標
0012040		
0012040-02	-22144.855	-9799.568
0012040-03	-22144.048	-9794.931
0012040-04	-22142.541	-9786.239
0012040-05	-22140.919	-9776.917
0012040-06	-22138.357	-9765.167
0012040-07	-22135.809	-9754.293
0012040-08	-22135.175	-9750.904
0012040-09	-22134.676	-9745.896
0012040-10	-22134.525	-9743.734
0012040-11	-22134.460	-9742.406
0012040-12	-22134.629	-9735.187
0012040-13	-22135.700	-9721.730
0012040-14	-22137.258	-9704.727
0012040-15	-22140.093	-9675.883
0012040-16	-22142.702	-9664.014
0012040-17	-22143.422	-9661.515
0012040-18	-22146.519	-9654.882
0012040-19	-22155.438	-9640.775
0012040-20	-22163.540	-9637.986
0012040-21	-22165.359	-9637.360
0012040-22	-22166.995	-9637.815
0012040-23	-22166.575	-9638.831
0012040-24	-22175.271	-9641.250
0012040-25	-22182.882	-9643.382
0012040-26	-22183.210	-9642.340
0012040-27	-22185.568	-9643.001
0012040-28	-22200.160	-9647.702
0012040-29	-22231.667	-9653.189
0012040-52	-22141.087	-9777.882
0012040-53	-22134.493	-9741.049
0012040-54	-22134.524	-9739.712
0012040-55	-22134.537	-9739.163
0012040-56	-22135.621	-9722.727
0012040-57	-22136.160	-9716.709
0012040-58	-22136.372	-9714.394
0012040-59	-22136.610	-9711.802
0012040-60	-22136.741	-9710.367
0012040-61	-22136.963	-9707.942
0012040-62	-22137.342	-9703.870
0012040-63	-22138.340	-9693.718
0012040-64	-22144.057	-9660.155
0012040-65	-22168.357	-9639.327
0012040-66	-22173.773	-9640.833
0012040-67	-22176.186	-9641.506
0012040-68	-22178.441	-9642.138
0012040-69	-22224.263	-9651.900
0012040-70	-22250.880	-9656.443

座標一覧表

点名	X座標	Y座標
0012050		
0012050-07	-22127.085	-9653.284
0012050-08	-22130.699	-9658.325
0012050-09	-22130.310	-9662.259
0012050-10	-22129.219	-9674.051
0012050-11	-22126.243	-9704.324
0012050-14	-22123.779	-9750.473
0012050-15	-22128.926	-9775.241
0012050-16	-22131.767	-9791.552
0012050-17	-22132.495	-9795.717
0012050-38	-22124.269	-9652.645
0012050-44	-22128.333	-9772.385
0012070		
0012070-21	-22146.130	-9634.911
0012070-22	-22140.166	-9644.344
0012070-23	-22129.848	-9648.309
0012070-32	-22141.951	-9641.520
0012070-33	-22128.638	-9648.035
0012080		
0012080-01	-22164.760	-9634.171
0012080-02	-22163.233	-9628.591
0012080-38	-22231.988	-9651.396
0012080-39	-22200.597	-9645.930
0012080-40	-22186.170	-9641.279
0012080-41	-22186.528	-9640.244
0012080-42	-22176.347	-9637.394
0012080-61	-22223.637	-9649.942
0012080-62	-22206.572	-9646.970
0012080-63	-22189.765	-9642.438
0012080-64	-22184.113	-9639.568
0012080-65	-22180.833	-9638.649
0012080-66	-22168.323	-9635.162

座標一覧表

点名	X座標	Y座標
基準点座標		
T1T1-TF167-2	-22131.347	-9776.093
T1T1-TF167-3	-22124.474	-9728.058
T1T1-TF167-4	-22127.338	-9698.009
T1T1-TF170-1	-22185.831	-9640.723
T1T1-TF170-2	-22225.859	-9652.606
T1交33	-22145.140	-9656.733
T1交34	-22149.348	-9631.717



T'42-2	T'43-1	T'43-2
T'42-4		T'43-4
T'52-2	T'53-1	T'53-2

⊕	基準点
⊗	市石杭
◇	市プレート
⊕	市
⊗	国調プレート
⊕	民石杭
⊗	民プレート
⊗	民
⊗	国石杭
⊗	国プレート
⊗	県石杭
⊗	県プレート
○	JR石杭等
□	JRプレート等
●	計算点