

A 栄町三丁目



S'35-3	S'35-4	T'31-3
S'45-1		T'41-1
S'45-3	S'45-4	T'41-3

⊕	基準点
⊗	市石杭
◇	市プレート
⊕	市 鉄
⊕	国調プレート
⊕	民石杭
⊕	民プレート
⊗	民 鉄
⊗	国石杭
⊕	国プレート
⊕	県石杭
⊕	県プレート
○	JR石杭等
□	JRプレート等
●	計算点

座標一覧表

点名	X座標	Y座標
0063011		
0063011-17	-22002.730	-10582.851
0063011-18	-22008.254	-10591.187
0063011-19	-22008.139	-10592.439
0063011-20	-22007.669	-10596.795
0063011-21	-22007.092	-10601.139
0063011-22	-22006.408	-10605.468
0063011-23	-22005.616	-10609.779
0063011-24	-22004.719	-10614.069
0063011-25	-22003.716	-10618.335
0063011-26	-22003.045	-10620.953
0063011-27	-21999.992	-10632.509
0063011-28	-21999.628	-10632.412
0063030		
0063030-02	-22022.622	-10644.718
0063030-03	-22050.702	-10652.188
0063030-04	-22053.213	-10652.828
0063030-05	-22058.216	-10653.936
0063030-06	-22063.262	-10654.835
0063030-07	-22068.340	-10655.523
0063030-08	-22073.442	-10656.000
0063030-09	-22075.667	-10656.141
0063030-10	-22078.560	-10656.264
0063030-11	-22083.684	-10656.313
0063030-12	-22088.806	-10656.150
0063030-13	-22093.918	-10655.773
0063030-14	-22099.008	-10655.183
0063030-15	-22100.914	-10654.907
0063030-16	-22123.627	-10651.433
0063030-17	-22125.347	-10661.620

座標一覧表


点名	X座標	Y座標
0063012		
0063012-01	-22024.158	-10638.917
0063012-02	-22027.214	-10627.343
0063012-03	-22027.980	-10624.356
0063012-04	-22029.123	-10619.489
0063012-05	-22030.147	-10614.595
0063012-06	-22031.050	-10609.678
0063012-07	-22031.831	-10604.739
0063012-08	-22032.489	-10599.783
0063012-09	-22033.026	-10594.812
0063012-10	-22033.439	-10589.829
0063012-11	-22033.561	-10587.980
0063012-12	-22033.805	-10582.986
0063012-13	-22033.926	-10577.987
0063012-14	-22033.924	-10572.987
0063012-15	-22033.900	-10571.562
0063012-16	-22033.797	-10567.989
0063012-17	-22033.548	-10562.996
0063012-18	-22033.176	-10558.010
0063012-19	-22032.680	-10553.034
0063012-20	-22032.062	-10548.073
0063012-21	-22031.322	-10543.128
0063012-22	-22030.460	-10538.203
0063012-23	-22029.475	-10533.301
0063012-24	-22028.371	-10528.424
0063012-25	-22027.147	-10523.577
0063012-26	-22026.032	-10519.379
0063012-27	-22031.062	-10510.736
0063012-32	-22121.577	-10619.568
0063012-33	-22121.581	-10625.522
0063012-34	-22121.979	-10635.519
0063012-35	-22122.871	-10645.479
0063012-36	-22100.007	-10648.975
0063012-37	-22098.194	-10649.238
0063012-38	-22093.351	-10649.799
0063012-39	-22088.490	-10650.158
0063012-40	-22083.618	-10650.313
0063012-41	-22078.743	-10650.266
0063012-42	-22075.992	-10650.149
0063012-43	-22073.875	-10650.015
0063012-44	-22069.022	-10649.561
0063012-45	-22064.191	-10648.906
0063012-46	-22059.392	-10648.052
0063012-47	-22054.633	-10646.998
0063012-48	-22052.244	-10646.389
0063012-49	-22122.125	-10578.982

座標一覧表

点名	X座標	Y座標
基準点座標		
3A162	-22005.642	-10512.326
3A163	-22029.432	-10570.177
3A163A	-22027.614	-10507.299
3A164	-22023.318	-10639.725
3A164A	-22010.487	-10589.641
3A215	-22079.186	-10654.209
3A216	-22125.442	-10535.581
20E05	-22124.320	-10611.841
R32K04	-22125.691	-10651.697



A 栄町三丁目



S'35-3	S'35-4	T'31-3
S'45-1		T'41-1
S'45-3	S'45-4	T'41-3